

TECHNICAL NOTES:

1. PROTECT SHEETS FROM SUN AND RAIN
2. INSTALL SHEETS WITH UV PROTECTION OUTWARDS
3. DON'T WALK ON PC SHEETS
4. DON'T WALK DIRECTLY ON THE PANELS DURING BOTH INSTALLATION AND MAINTENANCE. TO ACCESS THE ROOF USING SUITABLE RUNWAYS.

POLYCARBONATE CAN BE DAMAGED BY SOME CHEMICAL PRODUCTS. SO:

5. USE ONLY NEUTRAL SILICONE
6. FOR CLEANING USE ONLY WATER AND NEUTRAL DETERGENT

SHEETS ARE PRODUCED ON THE REQUIRED LENGTH WITH THERMOSEALED HEADS

7. SHEETS CAN BE CUT ON SITE WITH: JIGSAWS (1) OR CUTTERS (2). CLOSE THE HEADS AFTER CUTTING



8. DRILL ON SITE WITH SUITABLE DRILL BITS. MAKE HOLES IN THE SHEETS ACCORDING TO NEXT TABLE

Panel length	Hole - Asolatura	Slot hole A
mm	mm	mm
L ≤ 2000	10	
2000 < L ≤ 4000	14	
4000 < L ≤ 6000	18	
L > 6000	18 + 2,6 mm/m	


9. DRILLING FIXING:
 - 9.a. CORRECT:
 - 9.b. INCORRECT:

- 9.a. FIXING HAS TO BE ALWAYS PERPENDICULAR TO THE SHEET
- 9.b. DON'T TIGHTEN TOO MUCH THE SCREWS TO AVOID DAMAGING THE SHEETS.

10. PLEASE CONSULT OUR TECHNICAL DOCUMENTATION FOR LOAD RESISTANCE AND MAXIMUM SHEET LENGTH. **KG??**



MULTIPLE APPLICATION OVERLAP 2 SHEETS



C FIXING

- C1 LATERAL RIB: SCREW, WASHER, ALUMINUM CAP (Cod. 2S)
- C2 CENTRAL RIB: SCREW, WASHER, ALUMINUM CAP (Cod. 2F)